
# Notice about FINNESSE installation

From Higuchi-san's 2009 slides "FINNESSE Developer's guide (Belle note #791)"


### Plugging Out FINESSE from COPPER

The FINESSE has total 116 pins contacting with the COPPER.
 It is impossible to plug out the FINESSE by hand.



Do not forget to attach these chips on a FINESSE card, before you install it on a COPPER board. (Metal chips are available on Tsukuba B3F)
Otherwise you cannot plug out it later!

#### **FINESSE Dimensions**



## Appendix


## FINESSE/COPPER Connectors

- Straight, normal pitch
- 40 pins (20 x 2-rows) for connector-A,C



36 pins (18 x 2-rows) for connector-B

PRECI-DIP, 450-10-2xx-00-006001 (KEK elec. group uses)



## FINESSE/COPPER Connectors

- Straight, normal pitch
- 40 pins (20 x 2-rows) for connector-A,C

NEW

connector in case of bug

- · 36 pins (18 x 2-rows) for connector-B
- PRECI-DIP, 450-10-2xx-00-006001 (KEK elec. group uses)

